



KI-G100 <Main Kit>
IRIDIUM Ready GSM Handset

User Guide





Safety Precautions



The following are regulations and instructions concerning the safety of the phone user and of third parties. Please read these points carefully before using the phone. The manufacturer will not be responsible for any damage caused by non-observance of the User Guide and/or safety precautions.



Prohibited

- Do not switch on or use the phone at petrol stations or other sites with highly flammable fumes, as this could cause the gases to ignite or result in device damage, faults or a fire.



Prohibited

- Never operate the phone in an aircraft. Always switch it off before boarding. Its use may be hazardous to the aircraft's normal operation and may interfere with the airport's mobile radio networks. Failure to comply may result in prosecution.



Prohibited

- Do not use the phone in hospitals, as the antenna's electromagnetic radiation may cause disturbances to medical equipment's normal operation.



Essential

- If you wear devices such as a pacemaker or hearing aids, we recommend that you keep a safe distance from the antenna. The antenna's radiation may cause disturbances to their normal operation.



Essential

- Before making a call, fully extend the antenna. Do not touch or hold it during a call.



Essential

- We recommend the installation in a vehicle of the Hands Free Kit, which provides a safer alternative to holding and using the phone while driving. The Kit includes a handset cradle which allows for handsfree speech.



Essential

- Never expose the phone to high levels of moisture (e.g. rain, water jets...).

- This phone is only intended for use with approved accessories. Use of other such accessories may be dangerous and may invalidate any warranty or liability claims.

- Mobile phones may interfere with other electronic equipment's such as TV-sets, radios, computers/PCs, when used in their immediate surroundings.





Table of Contents

Safety Precautions..... front cover

Introduction	1
What's in the box	1
1. Getting Started	2
Insert your SIM Card	2
Attach the battery	2
Charge your battery.....	3
Carry strap.....	3
Switch on your phone.....	3
Your KI-G100 phone	4
Keypad and phone descriptions	4
Display description.....	5
2. Your First Call.....	6
Pull up the antenna	6
To make a call	6
To receive a call	6
To adjust the volume	7
To mute the microphone	7
To end or refuse a call.....	7
To redial.....	7
To switch off	7
3. Extra Dialling Services	8
Abbreviated Dialling	8
Speed retrieval.....	8
Direct access	8
Alphabetic access.....	8
Caller Log	9
Calling Line Identification	9
In-Call Menu	9
Call Waiting, Call Hold and Multiparty Calls.....	10
Active call(s) and waiting call.....	10
To put an active call on hold to make a second call.....	10
To swap between active and held call(s).....	11
To manage a "Multiparty" call	11
Manner Mode	11
Manner Talk Mode	11





4. Menus	12
How to use the menus.....	12
Main Menu structure.....	14
Memory Menu structure	15
Main Menu.....	16
1 Settings.....	16
2 Messages.....	16
3 Costs.....	18
4 Services	19
5 Network.....	20
6 Security	21
7 Accessory	22
8 IRIDIUM	23
Memory Menu.....	24
1 Phonebook.....	24
2 Dialed	26
3 Received	26
4 Erase.....	26
5 Own Number.....	26
5. IRIDIUM	27
6. Problem Solving / Helpful Hints	28
In case of a problem.....	28
Maintenance	29
Keypad letters allocation	29
Technical data	30
Licensing	30
7. Accessories	31
GSM accessories	31
IRIDIUM accessories.....	33
Index	35
Emergency call	rear cover





Introduction

Welcome!

Congratulations on choosing the Kyocera KI-G100 GSM phone for use on the GSM and IRIDIUM services. You have selected the unique digital phone designed to use the features offered by both the GSM cellular and the IRIDIUM satellite networks in a simple, friendly way.

Your KI-G100 phone has been designed to be easy to use - simply follow the self explanatory instructions on the display. Once you have mastered the basic concept of using the phone, you should only refer to this User Guide occasionally.

WHAT'S IN THE BOX

In your KI-G100 box you will find:


- KI-G100 handset
- Rechargeable battery, to power the phone
- Rapid charger, for charging the battery directly on the phone
- Carry Strap
- User Guide, that you should read thoroughly and retain for future reference
- Quick Manual
- Warranty Booklet

● IRIDIUM Ready
GSM Handset
(KI-G100)



Battery GC (BP-G100) included

● AC Charger GC (AC-G100)



● Carry Strap



Attach to the phone to use.




1. Getting Started

INSERT YOUR SIM CARD


The GSM SIM (Subscriber Identification Module) Card contains all the relevant information concerning your subscription (card number, phone number...). This card must be inserted in the phone prior to use.

Place the SIM Card (Plug-In size) in the phone as shown beside. Ensure that the gold chip is facing upwards and towards the bottom of the phone.




To remove the SIM Card:

- Press the release catch
- When the SIM Card pops up, pull it out




ATTACH THE BATTERY

- a. Hook the battery onto the hinge at the bottom of the phone
- b. Swing the battery down and click it into place




a:




b:

To remove the battery,

- a. Press the release catch
- b. Swing the battery up and then lift it off the phone



a:




b:



CHARGE YOUR BATTERY

Before using your phone for the first time or after a long period without use, it is important to charge the battery for at least 24 hours.


Plug the connector into the socket in the base of the phone, then plug the transformer unit into a mains AC power socket. In normal operation, the battery is fully charged when the bars in the battery symbol  stop moving.



Note: if the battery is completely discharged, the battery icon indicating the charge status will only appear 2 or 3 minutes after you connect the charger. We recommend to always discharge completely the battery before recharging.

CARRY STRAP

The Carry Strap included in the box can be fixed and removed as shown beside.



SWICH ON YOUR PHONE



- Press and hold the  key
- Enter the PIN code of your SIM Card (code provided together with the SIM Card)

If you make a mistake, use the  (Clear) key:

- short press: clear the last digit
- long press: clear the complete entry

- Press  (OK) to confirm

The phone is ready to be used when a network name is displayed.



Note: if you enter a wrong PIN code 3 times in succession, your SIM Card is blocked and you must enter the PUK code to unblock it (see section 5. Problem Solving / Helpful Hints on page 28).






YOUR KI-G100 PHONE

The keypad and the display are your way of communicating with your KI-G100 phone. They light up when you turn the phone on or press any key. The backlighting goes off automatically after 10 seconds, to conserve battery life.


Keypad and phone descriptions



1	Antenna	9	#/Scroll right	14	Earpiece
2	Alert speaker slots	10	Power/End/ Hang up	15	Status LEDs
3	LCD panel	11	Clear/Manner Mode toggle	16	Data and charger connector
4	Soft key 1	12	Soft Key 2	17	IRIDIUM connector
5	Speak/Redial	13	Rocker Key: Scroll Up-Down, press and hold to Select-Set	18	Battery/SIM release
6	~ Number/ /Symbol/Character			19	Battery
7	*/Scroll left/ P (pause)			20	Strap mount
8	Microphone				



Display description



1		Battery charge level: Fully charged Empty Charging
2		Roaming (receiving service on another network than your home network)
3		Calling status: - Blinking: call setup - On: call in progress
4		Short Message status: - On: new message waiting - Blinking: Short Message memory full
5		IRIDIUM system operation
6		GSM cellular operation
7		Incoming signal strength level
8		Number/text display area: - Numbers/text: 4 lines of 14 characters - On the lower right corner: "V" = vibration alert is on
9	Soft1	Left Softkey function label
10		Rocker Key function: Scroll Up/Down Volume Increase/Decrease (during a call) A/a Switch between Uppercase/Lowercase (during text entry)
11	Soft2	Right Softkey function label

2. Your First Call

PULL UP THE ANTENNA

Your KI-G100 phone is equipped with an extendable antenna. It is normally possible to make or receive calls with the antenna in, but better quality is obtained with the antenna extended.

 Fully extend the antenna **before** making or receiving a call. Never hold or touch it during the call.

Push the antenna in only after the call has ended.

TO MAKE A CALL

Before dialling a number, make sure that the coverage is sufficient, - a network name is displayed and there are at least 2 bars on the signal strength indicator. In case of poor coverage conditions, the reception quality may be improved by changing location (e.g. in a building move near to a window).

- Dial a telephone number, including the full area code, even if you are making a local call.

If you make a mistake, use the  (Clear) key:

- short press: clear the last digit
- long press: clear the complete number


- Press  (Call) or  to make the call



TO RECEIVE A CALL

The phone is ringing, the red light on top of the phone is blinking and "Incoming Call" is displayed:

- Press  (Answer),  or hold down the  key to answer the call




Note: while the phone is ringing, you can use the Rocker Key  ( ) to adjust the Ring volume.



TO ADJUST THE VOLUME

During a conversation, the volume can be adjusted with the Rocker Key  (+ -).



After the call the volume returns to its original setting (set in the Menu option "14 Ear Volume").



TO MUTE THE MICROPHONE

During a call the microphone can be muted so that your caller cannot hear you but you still can hear them.

- Press  (**Menu**)
- Scroll with  (▲ ▼) to the option "Mute" in the In-Call Menu
- Press  (**OK**) to confirm
- To reconnect the microphone, press  (**Unmute**) or hold down the  key



TO END OR REFUSE A CALL


The  key is used to end a call you have made or received, and also to refuse an incoming call.

TO REDIAL

In standby mode or during a call, the last 5 numbers dialled can be recalled and redialled.

- Press  to recall the outgoing call log
- Scroll  (▲ ▼) to the desired number to redial
- Press  to redial it

See also the Menu option "2 Dialled" page 26.



TO SWITCH OFF

- Press and hold  until "Powering Down..." is displayed.



3. Extra Dialling Services

ABBREVIATED DIALLING

There are different ways to recall and dial a phone number from the Phonebook:

Speed retrieval

- In standby mode, scroll with  (▲ ▼) to the desired number in the Phonebook.

Only the entries from the SIM Card's memory are listed here.




- Press  (Call), , or hold down the  key to call the selected number

Direct access

- In standby mode, enter a memory location number (of 1 to 3 digits)
If you make a mistake, use the  (Clear) key:
 - short press: clear the last digit
 - long press: clear the complete number
- Press  or scroll  (▲ ▼) from the desired location number in the Phonebook
- Press  (Call), , or hold down the  key to call the selected number

Alphabetic access (see also page 24)

- In standby mode or during a call, press  (Mem) to recall the Memory Menu
- Press  to select the submenu "1 Phone Book"
- Press  to select the submenu "1 Find"
- Press  to select the option "1 Name"
- Enter the beginning of a name (see p. 24)
- Press  (OK) or hold down the  key to view the matching name (if any)
- scroll with  (▲ ▼) from the desired name in the Phonebook
- Press  (Call), , or hold down the  key to call the selected number



CALLER LOG

Your KI-G100 is equipped with a caller log for identified calls (with telephone number if Calling Line Identification is available) that have been received. To recall this caller log, press  (**Mem**) and . See also the Memory Menu option "3 Received" page 26).


CALLING LINE IDENTIFICATION

The Calling Line Identification (CLI) service enables your phone to display the phone number of your caller. However, this will only occur if both parties have this service activated (see Menu "44 Caller id" p. 20).



IN-CALL MENU

During a call, you have access to a special "In-Call" Menu (the availability of its options depend on the call status, see next section).



- Press  (**Menu**) to access the In-Call Menu
- Select with  (▲ ▼):
 - Hold** to put the active call on hold (e.g. to make a second call)
 - or **Retrieve** to reactivate a held call
 - or **Exclude** to select one of the parties to be put on hold
 - or **Swap** to put the active parties on hold and reactivate the held ones
 - End** to hang up the active call
 - or **Drop** to select one of the parties to be hanged up
 - (Join All)** to reactivate all parties (if multiparty call, all parties held)
 - (Hold all)** to put all parties on hold
 - (Private)** to activate one party only and leave all others on hold
 - Tones Off** to switch off the DTMF tones
 - or **Tones On** to switch on the DTMF tones
 - (Cost** to display cost information (if available)
 - or **Total Cost)** to display total cost information (if available)
 - Mute** to mute the microphone
 - Quit** to leave the In-Call Menu and return to the In-Call screen
- Press  (**OK**) to confirm

CALL WAITING, CALL HOLD AND MULTIPARTY CALLS


The GSM services “Call Waiting” and “Call Hold” allow you to put an active call on hold to be able to answer a waiting call or initiate a new call. The “Call Waiting” function can be activated in menu “43 Waiting”. If this function is disabled, you will not be notified of a waiting call. A second caller will either hear the busy tone or their call will be diverted according to the set diversion. If the function is enabled, the caller will hear the ringing tone and you will be also notified.

The “Multiparty” (Mtpy) service allows you to speak to up to 5 other parties on the same call.

Active call(s) and waiting call


One or more calls are active and a new one is waiting (indicated by a signal tone through the earpiece and red light on top of the phone blinking):

- Press  to end all active and held calls and then  to accept the new call,
or
- Press  (Menu) to access the Call Waiting Menu
- Select with  (▲ ▼):
 - Answer** to answer the waiting call, thus putting on hold the active ones
 - Replace** to hang up all active calls and accept the new one
 - Reject** to reject the waiting call. Their call will be dropped.
 - I am busy** to let the waiting caller hear the busy tone or let their call being diverted if the diversion *When Busy* has been set
 - Quit** to leave the Call Waiting Menu
- Press  to confirm



To put an active call on hold to make a second call

- Press  (Menu) to access the In-Call Menu
- Select with  (▲ ▼) the option “Hold”
- Press  to confirm
- Dial a number and make the second call





To swap between active and held call(s)

- Press (Menu) to access the In-Call Menu
- Select with (▲ ▼):
 - Retrieve** if there is only one held party and one active call
 - Swap** if there are more held parties and active calls
- Press (OK) to confirm




To manage a “Multiparty” call

A multiparty call can be managed with the “Exclude”, “Drop”, “Join All”, “Hold All” and “Private” options of the In-Call Menu (see previous section).

MANNER TALK MODE

The Manner Talk Mode allows you to make a call in noisy environment with a higher comfort. The sensitivity of the microphone is increased and surrounding noises are filtered so you don't need to speak louder, and the earpiece volume is increased. When the Manner Talk Mode is activated, “M” is displayed above the right softkey's label.



- During a call, a long press on activates or deactivates the Manner Talk mode.



4. Menus

Please read this introduction to get the most out of the menus and their features.


- Your KI-G100 features 2 principal menus: the Main Menu and the Memory Menu.
- The menu structures are illustrated at the end of this introduction.
- In standby mode, the Main Menu can be accessed by pressing the left Softkey  (Menu) and the Memory Menu by pressing the right Softkey  (**Mem**) or holding down the Rocker Key .
- Scroll in a menu by using the Rocker Key  ( ) or access a menu option directly by entering its menu access code.
- A menu or option is selected when it is highlighted.
- The  symbol beside a menu option indicates the presence of a submenu.
- The  symbol indicates the option which is currently set.
- A selected option can be confirmed by pressing  (**OK**) or holding down the  key, then a sub-menu or a result screen is displayed.
- In a menu, pressing the End Key  will move back to the previous menu level.
- When a call is received while you are in the menu mode, the menu function is automatically interrupted. Simply accept the call by pressing the Call Key .
- During a call, only special In-Call menus are available.

HOW TO USE THE MENUS

You may access a menu option in 2 different ways:

Example: access to the function "Display the duration of the last call" of the Main Menu.


(Standby mode)






A. Access the menu option by scrolling


- Press (Menu) to access the Main Menu



- Scroll with (▲ ▼) to option “3 Costs”




- Press (**OK**) to confirm and enter the submenu “Costs”



- Press (**OK**) to confirm and enter the submenu “Last Call” already selected

- Scroll with (▲ ▼) to option “2 Duration”



- Press (**OK**) to confirm and read the last call duration


B. Access the menu option directly by entering its access code

- Enter the sequence (Menu) **3DEF** **1** **2ABC** to recall the function directly (MENU 312).

In the following descriptions, we will simply label any menu or option with its direct access code.




MAIN MENU STRUCTURE




(continued on next page)

(from previous page)



Note: Menu “8 IRIDIUM” is only available when the KI-G100 is docked on the Iridium Adapter SD-66K (optional)

MEMORY MENU STRUCTURE





MAIN MENU

1 SETTINGS

This menu allows you to choose particular settings for your phone.

- 11 Language** select one of 13 languages for the display screens
- If you have selected another language and wish to get back to English, enter the sequence:**
☐ (Menu) ☐☐, scroll to "English" and confirm
- 12 Ringer**
- 1 Ring Type** select one among 6 different ringing tones
 - 2 Ring Volume** select a volume level or the stepped increasing volume
 - 3 Ring/Vibrate** select how an incoming call is notified. If Vibrator is selected, "V" is displayed on the standby screen.
 - 4 Eyes Call** set how long the ringing tones will sound
- 13 Any Key Answer** if set, any key except ☐ will answer an incoming call
- 14 Ear Volume** set the default earpiece volume
- 15 Key Volume** set the keypad tone volume
- 16 DTMF Tones** switch on or off the generator of Dual Tone Multi Frequency tones generator for the control of answering machines, homebanking etc during a call
- 17 Display**
- 1 Backlight** switch on or off the automatic backlighting
 - 2 Contrast** set the LCD panel contrast

2 MESSAGES

Your KI-G100 phone is able to receive and send SMS (Short Message Service) text messages. These are stored on the SIM Card, not in phone itself, and their number depends on the Card's storage capacity. As soon as a new message is received, the ☐ symbol is displayed and will only disappear when all new messages are read. You can directly call (or transfer into the Phonebook) the telephone number given in the message itself. A received message can be edited and resent.

Broadcast messages such as traffic or whether information are sent from the network to a group of users.





21 Text

1 Read new read all unread message(s) that have been received:

- Scroll in the message with  (▲ ▼)
- Press  (**Menu**) to access the Message Menu and select

- 1 Read Next** (appears only if there is at least one other to read)
- 2 Edit** to edit the message (see next section)
- 3 Reply** to reply to the message's sender (see next section)
- 5 Extract** to extract the number included in the message
- 6 Erase** to erase the message
- 7 Info** to display additional information about this message

2 Read all read all messages: same procedure as above

3 Create write a new message:

- Enter a message (max. 160 characters)
 - To enter a letter, press a key several times until the desired letter appears (see keypad allocation page 29)
 - Use  (A/a) to toggle between upper- and lowercase
 - If you make a mistake, use the  (Clear) key:
 - short press: clear the last character
 - long press: clear the complete entry
- Press  (**OK**) and enter a destination number
- to access the Create Message Menu and select:

- 1 Save** to save the message first
- 2 Send** to send the message first

4 Settings changing of message control settings:

- 1 Msg Centre** tel no. of the network unit which routes the messages
- 2 Reply Path** let the answer to your message be prepaid
- 3 Valid per** set the validity duration for not transmitted message

22 Broadcast

1 Read new read unread message(s) sent by the network

- Scroll in the message with  (▲ ▼)
- Press  (**Menu**) to access the Message Menu and follow the same procedure as in previous section

2 Read all read all messages: same procedure as above

3 Configuration select the type and language of the messages to be



received from the net work

3 COSTS

An indication of the cost of a call and its duration can be displayed during the call itself or after it. You can also see an indication of the cumulative cost of all calls and their total duration since the last reset.

Since the currency factor and monetary unit for the cost indication is stored on your SIM Card, the PIN2 code of the SIM Card is required to modify them (contact your Service Provider to obtain the PIN2 code of the SIM Card).



Note: if you enter the wrong PIN2 code 3 times in succession, the PIN2 function of your SIM Card is blocked and you must enter the PUK2 code to release it (contact your Service Provider).

A charge or duration limit can be set so that when elapsed, calling becomes automatically impossible. The PIN2 code of your SIM Card is also required to activate and manage this function.

31 Last Call

- | | |
|-------------------|--|
| 1 Cost | display an indication of the cost of the last call |
| 2 Duration | display the duration of the last call |

32 All Calls

- | | |
|-------------------|---|
| 1 Cost | display an indication of the cumulative cost of all calls |
| 2 Duration | display the cumulative duration of all calls |
| 3 Reset | reset the cumulative cost and duration timers |

33 Max cost

- | | |
|-----------------------|--|
| 1 Read Limit | display the set charge or duration limit (PIN2 required) |
| 2 Change Limit | change the charge or duration limit (PIN2 required) |

34 Currency

- | | |
|-----------------|---|
| 1 Read | display the set currency (PIN2 required) |
| 2 Change | change the charge or duration limit (PIN2 required) |



4 SERVICES

41 Barring

This service must be included in your subscription package to be accessible. Your Service Provider will then give you a Barring Password to set and clear barrings.

- Select
 - 1 Int. calls** to inhibit outgoing international calls
 - 2 Except home** to inhibit outgoing calls except those to your home network
 - 3 Incoming** to inhibit all incoming calls or only incoming calls when you are roaming (receiving service other than from your home network)
 - 4 Outgoing** to inhibit all outgoing calls
 - 5 Cancel all** to clear all barrings at the same time
 - 6 Password** to modify your Barring Password

- Confirm
- Eventually, select "All Calls" or "If Abroad" for the option "3 Incoming" and confirm again
- Enter your Barring Password and confirm

42 Divert

You can choose to divert your incoming calls to another telephone anywhere (for example to your office or a friend's house) or to your Voicemail, so that you are not disturbed, e.g. in a meeting or a restaurant. You can decide whether you want to divert all calls or those if you are engaged, if you don't wish to answer and/or are unreachable.

- Select
 - 1 All Calls** to divert all incoming calls
 - 2 When busy** to divert incoming calls while you are engaged on a call
 - 3 No answer** to divert incoming calls if you don't answer within a certain time that you can set between 5 and 30 seconds
 - 4 Not found** to divert incoming calls if your phone is switched off or is out of coverage
 - 5 Cancel all** to clear all diversions at the same time



- Confirm, enter a new or edit the current destination number, and confirm
- Eventually, select a duration for "Divert on *No answer*" and confirm

43 Waiting

With this menu you can switch the "Call Waiting" function on or off, or check the function status within the network. If it is on, you will be notified that a caller is waiting while you are already engaged (provided that there is no diversion set of all calls, see previous section). If the function is off, you will not be informed that a second call is waiting and the caller will hear the busy tone or their call will be diverted if diversion *When busy* is set. See "Call Waiting, Call Hold and Multiparty Calls" information on page 10.

44 Caller id

With this menu you can choose whether the telephone number of someone or a party calling you will be displayed (provided the function is activated on their side) and whether your telephone number will be transmitted to someone or a party you are calling.

- Select and confirm
 - 1 Far id** to set the display of the number of someone calling you
 - 2 Your id** to set the display of your number to someone you are calling
- Select and confirm
 - 1 Presentation** to enable the telephone number display
 - 2 Restriction** to inhibit the telephone number display

5 NETWORK

If your home network is not in range your phone tries to register onto another available GSM 900 network, following the priority given in the network list stored on your SIM Card. This menu allows you to edit this list.

If no network from the list has been found, the phone will then try to register on a network listed in the phone's network list.



6 SECURITY

Here you can lock the keypad, enable or disable the SIM Card's PIN check, change its PIN code, change its PIN2 code, enable or disable the Fixed Dialling Memory (FDN) function.

61 Key Lock

The keypad can be locked in standby mode to avoid any undesired function (e.g. accidental dialling). In that case, only the key can be used to switch off the phone.

- To unlock the keypad in standby mode, press and hold the left Softkey .

During an incoming call, you will be prompted to unlock the keypad to answer the call:

- Press and then to answer the call



62 PIN

If this function is activated, your SIM Card is protected against unauthorised use with a Personal Identification Number (PIN) of your choice, that will be requested each time the phone is switched on.

63 New PIN

You can change here the PIN code of your SIM Card. It must contain a minimum of 4 and a maximum of 8 digits.



Caution: if you enter the PIN code incorrectly 3 times, your SIM Card will be blocked and you must enter the PUK code to unblock it (see section "6. Problem Solving / Helpful Hints").

64 New PIN2

The PIN2 code of your SIM Card allows you to access some special functions of the SIM Card such as the setting of charge parameters (see Menu "3 Costs") or the Fixed Dialling Numbers function (see Menu "65 FDN").





You can change here the PIN2 code of your SIM Card. It must contain a minimum of 4 and a maximum of 8 digits.



Note: if you enter the wrong PIN2 code 3 times in succession, the PIN2 function of your SIM Card is blocked and you must enter the PUK2 code to unblock it (contact your Service Provider).

65 FDN

The PIN2 code is required to enable or disable this function. If it is enabled, only Fixed Dialling Numbers stored on the SIM Card, extensions of these numbers and emergency numbers can be dialled. The access to the SIM memory is also restricted. This can be used for example when you lend your phone to someone else and wish them to be only able to call certain numbers, e.g. in your office. This setting has no effect on the Short Messages function.

Note: switching FDN on or off may require dozens of seconds.

7 ACCESSORY

You can set some parameters for the use of your phone in a vehicle, with the Hands Free Kit (see page 31).

71 Auto Answer

With this function activated, a call will be answered automatically after 2 rings. This will only occur if the ignition is on.

72 Off Timer

You can set here the delay after the ignition key has been removed the phone will be powered off. The Off Timer can be set within a range from 0 to 99 minutes.





8 IRIDIUM

This menu allows you to perform the settings related to the IRIDIUM satellite operation. It is only shown when the IRIDIUM Adapter (accessory) is attached. Please refer to the section "5. IRIDIUM" for more information.

81 Registration

This performs a manual registration request on the IRIDIUM satellite network.

82 DTMF Tones

You can choose here whether the DTMF tones will be transmitted during a call for a fixed period of time when keys are pressed (setting "Short") or as long as the keys are being pressed (setting "Long").

83 Services

The settings for Call Barring, Call Divert and Call Waiting on the IRIDIUM network can be performed in a similar way as in Menu "4 Services" for the GSM cellular operation.

Please notice, however, that Call Barring can only be set for all incoming and/or all outgoing calls, and that Call Divert on *No Answer* is not available.

84 Modes

Should both a GSM cellular network and the IRIDIUM satellite network be in range of your phone, your KI-G100 phone with its IRIDIUM attachment will register on one of them according to the priority set in this menu. If a preferred mode is stored in the SIM Card, this one will be adopted automatically.

- Select and confirm
 - 1 GSM only** to allow the phone to register always on a GSM cellular network, never on the IRIDIUM satellite network
 - 2 IRIDIUM only** to allow the phone to register always on the IRIDIUM satellite network, never on a GSM cellular network
 - 3 Dual-1** to allow the phone to register on both, but with priority on a GSM cellular network
 - 4 Dual-2** to allow the phone to register on both, but with priority on the IRIDIUM satellite network



MEMORY MENU

1 PHONEBOOK

Your Phonebook consists in 3 different memories for storing phone numbers:

- SIM Card Memory: memory locations 1 to 300
- Phone Memory: memory locations 301 to 600
- FDN (Fixed Dialling Numbers) SIM Memory: memory locations 601 to 999

The number of possible entries in the SIM and FDN Memories depends on the capacity of your SIM Card.

11 Find search a Phonebook entry by name or location number

1 Name

- Enter the beginning of a name
 - To enter a letter, press a key several times until the desired letter appears (see keypad allocation page 29)
 - Use  (A/a) to toggle between uppercase and lowercase
 - If you make a mistake, use the  (Clear) key:
 - short press: clear the last character
 - long press: clear the complete entry
- Press  (OK) to view the matching name (if any)
- Scroll  ( ) from the desired name. Entries are sorted alphabetically
- Press  (Call) or  to call the selected number

2 Location

- Enter a location number (1 to 3 digits)
- Press  (#>) to view the matching name (if any)
- Scroll  ( ) from the desired name. Entries are sorted by location number
- Press  (Call) or  to call the selected number



12 New create an entry in the Phonebook (SIM, Phone or FDN Memory according to the location number)

- Enter a name
 - To enter a letter, press a key several times until the desired letter appears (see keypad allocation page 29)
 - Use  (A/a) to toggle between upper- and lowercase
 - If you make a mistake, use the  (Clear) key:
 - short press: clear the last character
 - long press: clear the complete entryand confirm it
- Enter the telephone number (use  to insert a pause) and confirm it
- Select the "Phone", "SIM" or "FDN" Memory, and confirm
- Eventually, enter and confirm the PIN2 code to access the FDN Memory
- Eventually, edit the suggested location number, and confirm

13 Edit change an entry in the phonebook (SIM, Phone or FDN Memory according to the location number)

- Find the entry to edit (same procedure as in menu "11 Find")
- Edit name and number, and confirm
- Select "Overwrite" to keep the same location number or "Other" to change it, and confirm
- If "Other" has been chosen, select the "Phone", "SIM" or "FDN" Memory, and confirm,
- Eventually, enter and confirm the PIN2 code to access the FDN Memory
- Eventually, edit the suggested new location number, and confirm

14 Edit delete an entry in the phonebook (SIM, Phone or FDN Memory according to the location number)

- Find the entry to delete (same procedure as in menu "11 Find")
- Eventually, enter and confirm the PIN2 code to access the FDN Memory
- Confirm the deletion of the entry





2 DIALLED

This function allows you to display the 10 last dialled numbers. These are either stored on the SIM Card (if the SIM supports this function) or in the phone. If you dial the same number more than one time, this number will appear only once in the list.

You can recall the dialled number list to call again or store in the phonebook a particular number (option "Save").

3 RECEIVED

Your KI-G100 phone is equipped with a caller log for identified calls (with telephone number if Calling Line Identification is available) that have been received. If you have been called by the same number more than one time, this number will appear only once in the list.

You can recall the received number list to call back or store in the phonebook a particular number (option "Save").

4 ERASE

This function allows you to clear completely the SIM, Phone or FDN Memory. The process may require dozens of seconds.

- Select the "Phone", "SIM" or "FDN" Memory, and confirm
- Eventually, enter and confirm the PIN2 code to access the FDN Memory

5 OWN NUMBER

The phone number of your SIM Card can be recalled, for example to give it to someone. Should this number not be stored already on the SIM Card, you can enter it here.


- Press the "Edit" softkey and enter your SIM Card telephone number
- Press the "Save" softkey to store it





5. IRIDIUM


By attaching the Kyocera IRIDIUM Adapter SD-66K (accessory) to your KI-G100 phone, you transform it into an IRIDIUM compatible handset capable of communicating directly with the IRIDIUM satellite network.



The IRIDIUM network consists of 66 satellites covering 100% of the earth surface, 100% of the time. This makes it possible for the IRIDIUM system to offer communications anywhere, anytime, to anyone.

The network uses six polar orbital planes at an angle of 86.4 degrees to the equator. Each orbital plane contains eleven operational satellites and a spare one placed in a storage orbit below the eleven operational satellites. The satellites orbit at a speed of approx. 28000 km/h and at an altitude of 780 km or 421.5 nautical miles making the IRIDIUM constellation a low earth orbit system. The six satellite rings are slowly moving to the west due to the Earth's rotation from west to east. The satellites make their closest approach to one another over the north and south pole, but never come closer to one another than 195 kilometres or 105 nautical miles. The satellites carry enough fuel on board to remain in orbit for 8 years. The normal life expectancy of a single satellite is 5 to 8 years.





Each IRIDIUM satellite is communicating with the next one, so that a call is routed within the constellation before it goes down to earth via a terrestrial gateway. A single IRIDIUM satellite footprint has a diameter of approx. 4400 km. As the user approaches the perimeter of the satellite's footprint a second satellite footprint appears. Once the user is within the coverage of the second satellite footprint a hand off to the second satellite occurs. Satellite handoffs continue to occur so every 9 minutes approximately as long as the IRIDIUM user is on air.

With conventional terrestrial cellular systems, the cells are fixed and the user moves from cell to cell causing handoffs to occur. In the IRIDIUM system the cell pattern moves across the user's location which causes handoffs to occur.

Although it uses a satellite network instead of a terrestrial one, IRIDIUM is also a GSM operator, interconnecting in the same way with other GSM terrestrial operators and using the same type of SIM Cards. Therefore, unless you use an IRIDIUM SIM Card, you can "roam" on the IRIDIUM network as you would do so on another GSM network provided you have the IRIDIUM Adapter attached to your KI-G100 phone and your home Network Operator has a Roaming Agreement with Iridium.

When using your KI-G100 phone with its IRIDIUM Adapter on the IRIDIUM network, please make sure that you are located outside, in a free area, i.e. not between tall buildings ("urban canyon") or trees that would limit the satellite visibility. Always dial a telephone number with its country code (e.g. +49 2159 918396).



6. Problem Solving / Helpful Hints

IN CASE OF A PROBLEM

Before contacting the Kyocera Helpline, please observe the following.

If the display shows “PIN is blocked”:



The PIN code has been entered incorrectly three times, you need the PUK (PIN Unlocking Key) to release it.

- Decide on a new PIN
- Enter the following sequence:

*< *< 0+ 5.ML *< [PUK] [new PIN] [new PIN] .



Caution: if you do not know your PUK, do not try to unblock your SIM Card, as this will lead to it becoming permanently blocked, and you will be charged by your Service Provider for a replacement SIM Card. Contact your Service Provider who will give you the PUK and help you to unblock your SIM Card.

If none of the Ψ , ∇ and μ symbols are showing:



The network connection is lost. Either you are in a radio shadow (in a tunnel or between tall buildings) or you are outside of the network coverage area. Try from another place.

If the display doesn't respond (or responds slowly) to key presses:



The display responds more slowly at very low temperatures. This is normal and does not affect the operation of the phone. Take the phone to a warmer place and try again.

If your phone does not go to the standby mode:



Switch off the phone, check that the SIM Card and battery are installed correctly and switch on again.



MAINTENANCE

The equipment i.e. phone and charger do require some care. Please observe the following:

- Store it in a clean, dust-free space. Its moving parts can be damaged by dust.
- Keep it away from hot locations. High temperatures can shorten the life of the electronic components and batteries, and warp or melt certain plastics.
- Do not try do disassemble the phone. If it is not working properly, call the Kyocera Helpline.
- Use only the recommended battery chargers.
- Treat the phone gently and avoid dropping, knocking or shaking it.
- Keep the equipment out of reach of small children.
- Keep the phone dry and do not use harsh chemicals (such as solvents or detergents) to clean it. To clean the phone, wipe it with a soft cloth slightly dampened with a mild solution of soap and water.
- Always let your battery discharge completely before recharging it.

KEYPAD LETTERS ALLOCATION

The table below shows how letters are allocated to the 10 number pad keys.

Key	Characters Uppercase Mode	Lowercase Mode
1	SP- _ . , : ; ' " ? ! j 1	SP- _ . , : ; ' " ? ! j 1
2 ^{ABC}	A B C à Á Â Æ Ç 2	a b c à á â æ ç 2
3 ^{DEF}	D E F è É Ê Æ 3	d e f è é ê æ 3
4 ^{GHI}	G H I Ì 4	g h i ì 4 ← ï
5 ^{JKL}	J K L Λ 5	j k l Λ 5
6 ^{MNO}	M N O Ñ Ò Ó Ø 6	m n o ñ ò ó ø 6
7 ^{PQRS}	P Q R S β Π Θ Σ 7	p q r s β π θ σ 7
8 ^{TUV}	T U V Û Ü 8	t u v ù ü 8
9 ^{WXYZ}	W X Y Z Ω Ξ Ψ 9	w x y z ω ξ ψ 9
0 +	* # / (< = > + % £ \$ ¥ ¢ @ & § 0	* # / (< = > + % £ \$ ¥ ¢ @ & § 0
* <	Move left	Move left
# >	Move right	Move right

TECHNICAL DATA**KI-G100 (main unit)**

Max. output power:	2 Watt
Power supply:	DC 3.6 V - 600 mAh Li-Ion battery
Standby time GSM*:	approx. 70 hours
Talk time GSM*:	approx. 120 minutes
Standby time IRIDIUM*:	approx. 24 hours
Talk time IRIDIUM*:	approx. 100 minutes
SIM Card size:	Plug-In
Dimensions (excl. Antenna):	approx. 130 x 41 x 22 mm (L x W x H)
Weight:	99 g
Operating temperature:	-10°C ~ 55°C
Data speed:	9600 bps

* depending on network coverage and system parameters offered by the network operator.

AC-G100 (AC Charger)

Dimensions:	approx. 130 x 40 x 25 mm (L x W x H)
Weight:	60 g
Input:	AC 90~240 V, 50/60 Hz, 4 VA
Output:	DC 4.1 V, 600 mAh
Charging time:	approx. 90 minutes

LICENSING

Your KI-G100 phone and its accessories detailed in the following section are authorised for use on GSM 900 networks.

The phone complies with EU standards

... (tbc)

...


confirmed by the CE label.

7. Accessories


The following Kyocera original accessories have been designed especially to work with your KI-G100 phone. Additional accessories may be available and are sold separately. Please contact your local Service Provider or retail outlet for more information.

GSM ACCESSORIES


DC Charger GC (Ref. DC-G100)




Two Way Cable GC (Ref. TW-G100)




Desktop Charger GC (Ref. DE-G100)




Hands Free Kit GC (Ref. HF-G100)



Data Cable GC (Ref. DA-G100)



Car Holder GC (Ref. CH-G100)







Soft Case GC (Ref. SG-G100)



External Antenna GC (Ref. OA-G100)




Personal Hands Free GC (Ref. EM-G100)




IRIDIUM ACCESSORIES


IRIDIUM Adapter (Ref. SD-66K)




IRIDIUM Hands Free Kit (Ref. HF-S100)




IRIDIUM AC Charger (Ref. AC-S100)



IRIDIUM Car Holder (Ref. CH-S100)




IRIDIUM DC Charger (Ref. DC-S100)




IRIDIUM External Antenna (Ref. OA-S100)




IRIDIUM Solar Power Supply
(Ref. SP-S100)



Personal Hands Free GC
(Ref. EM-G100)




Data Cable GC (Ref. DA-G100)



IRIDIUM Separate Vibrator
(Ref. SV-S100)



IRIDIUM Two Way Cable
(Ref. TW-S100)





Index

(to be inserted in the final version)





Notes:



Emergency Call

TO MAKE AN EMERGENCY CALL:

- Press and hold  to switch on the phone
- If required, enter the SIM Card's PIN code and confirm with  (OK)
- Enter    (112 is the international GSM emergency call number)
- Press  to make the call

Give the following information to the emergency service:

- Your name
- The location of the accident
- What happened
- The number of injured persons (if any)
- When the accident occurred
- If possible, give your phone number for callback. Remember to leave your phone switched on for incoming calls.



Short User Guide (credit card size, printed on both sides)

Side 1:

Short User Guide  **KI-G100**

To switch on: press and hold  until a message appears.
If required, enter the SIM Card's PIN and confirm with  (OK).

Your phone is ready to be used when a network name is displayed.

To make a call:  Telephone no. 

To end or refuse a call: 

To redial:  

To receive a call (telephone ringing, light blinking): 

To switch off: hold  until "Powering Down..." is displayed.

Side 2:

Abbreviated dialling

a.  

b.  1 to 3 digit location number  

c.  (Mem)    Letter or name  (OK) 

Menu:

To access the menu:  (Men)

To scroll/select an option: 

To confirm:  (OK)

To move back to the previous menu level: 

To exit a menu: 

